

## Damper actuator for operating air control dampers in ventilation and air-conditioning systems for building services installations

- For air control dampers up to approx. 8 m<sup>2</sup>
- Torque 40 Nm
- Nominal voltage AC 100 ... 240 V
- Control: Open-close
   (not made for 3-point applications)



**Technical data sheet** 

## Technical data

Electrical data	Nominal voltage		AC 100 240 V, 50/60 Hz
	Nominal voltage range		AC 85 265 V
	Power consumption	In operation	5 W @ nominal torque
		At rest	2 W
		For wire sizing	9 VA
	Connection		Cable 1 m, 3 x 0.75 mm <sup>2</sup>
Functional data	Torque (nominal torque)		Min. 40 Nm @ nominal voltage
	Direction of rotation		Reversible with switch 0 K or 1 C
	Manual override		Gearing latch disengaged with pushbutton, detentable
	Angle of rotation		Max. 95°⊄, limited on both sides
			by means of adjustable, mechanical end stops
	Running time		150 s / 90°⊄
	Sound power level		Max. 45 dB (A)
	Position indication		Mechanical, pluggable
Safety	Protection class		II Totally insulated $\Box$
	Degree of protection		IP54 in any mounting position
	EMC		CE according to 89/336/EEC
	Low voltage directive		CE according to 73/23/EEC
	Mode of operation		Type 1 (EN 60730-1)
	Rated impulse voltage		2.5 kV (EN 60730-1)
	Control pollution degree		3 (EN 60730-1)
	Ambient temperature range		–30 +50 °C
	Non-operating temperature		–40 +80 ° C
	Ambient humidity range		95% r.H., non-condensating (EN 60730-1)
	Maintenance		Maintenance-free
Dimensions / Weight	Dimensions		See «Dimensions» on page 2
	Weight		Approx. 1'700 g

## Safety notes



The damper actuator is not allowed to be used outside the specified field of application,

- especially in aircraft or any other form of air transport.
- Caution: Power supply voltage !
- Assembly must be carried out by trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The cable must not be removed from the device.
- When calculating the required torque, the specifications supplied by the damper manufacturers (cross section, design, installation site), and the air flow conditions must be observed.
- The device contains electrical and electronic components and is not allowed to be disposed of as household refuse. All locally valid regulations and requirements must be observed.



	, supplied with				
	, supplied with				
	Simple direct mounting on the damper spindle with a universal spindle clamp, supplied with an anti-rotation strap to prevent the actuator from rotating.				
Manual operation is possible with the pushbutton (the gearing latch remains disengaged as long as the pushbutton is pressed or detented).					
Adjustable angle of rotation with mechanical end stops.					
The actuator is overload-proof, requires no limit switches and automatically s end stop is reached.	tops when the				
Description	Data sheet				
Auxiliary switch, type SA	T2 - SA				
Feedback potentiometer, type PA	T2 - PA				
Various accessories (Damper and actuator crank arms, anti-rotation strap etc.)	T2 - Z-GMA				
Electrical installation					
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$					
$\begin{array}{c} \hline \\ \hline $					
,	<ul> <li>Adjustable angle of rotation with mechanical end stops.</li> <li>The actuator is overload-proof, requires no limit switches and automatically s end stop is reached.</li> <li>Description <ul> <li>Auxiliary switch, type S.A</li> <li>Feedback potentiometer, type P.A</li> </ul> </li> <li>Various accessories (Damper and actuator crank arms, anti-rotation strap etc.)</li> </ul> <li> <ul> <li>Auxiliary switch accessories (Damper and actuator crank arms, anti-rotation strap etc.)</li> </ul> </li> <li> <ul> <li>Auxiliary switch type S.A</li> <li>Feedback potentiometer, type P.A</li> </ul> </li> <li> <ul> <li>Various accessories (Damper and actuator crank arms, anti-rotation strap etc.)</li> </ul> </li> <li> <ul> <li>Auxiliary switch accessories (Damper and actuator crank arms, anti-rotation strap etc.)</li> </ul> </li> <li> <ul> &lt;</ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul></li>				





















