

### **Technical data sheet**

# Rotary actuator for 2 and 3-way (control) ball valves

- Torque 5 Nm
- Nominal voltage AC 100 ... 240 V
- Control: Open/close or 3-point



#### **Technical data**

Electrical data	Nominal voltage	AC 100 240 V, 50/60 Hz
	Power supply range	AC 85 265 V
	Power consumption In operation	1.5 W at nominal torque
	At rest	0.4 W
	For wire sizing	4 VA
	Connection	Cable 1 m, 3 x 0.75 mm <sup>2</sup>
	Parallel connection	Possible, note performance data
Functional data	Torque (nominal torque)	Min. 5 Nm at nominal voltage
	Manual override	Gearing latch disengaged with pushbutton
		(temporary-permanent)
	Running time	90 s / 90° ∢
	Noise level	Max. 35 dB (A) (without the valve)
	Position indication	Mechanical, add-on
Safety	Protection class	II Totally insulated
	Degree of protection	IP54 in any mounting position
	EMC	CE according to 89/336/EEC
	Low voltage directive	CE according to 73/23/EWG
	Mode of operation	Type 1 (to EN 60730-1)
	Rated impulse voltage	4 kV (to EN 60730-1)
	Control pollution degree	3 (to EN 60730-1)
	Ambient temperature range	0 +50 °C
	Media temperature	+5 +110°C in (control) ball valve
		-10°C with stem heating upon request
	Non-operating temperature	–40 +80°C
	Ambient humidity range	95% r.H., non-condensating (to EN 60730-1)
	Maintenance	Maintenance-free
Dimensions / Weight	Dimensions	See «Dimensions» on page 2
	Weight	Approx. 550 g

Safety notes



• The rotary actuator has been designed for use in stationary heating, ventilation and air conditioning systems and is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.

- Caution power supply voltage!
- It may only be installed by suitably trained personnel. All applicable legal or institutional installation regulations must be complied with.
- The switch for changing the direction of rotation may only be operated by authorized
- personnel. The direction of rotation must not be reversed in a frost protection circuit.
  The device may only be opened at the manufacturer's site. It does not contain any parts that
- can be replaced or repaired by the user.
- The cable must not be removed from the device.
- The device contains electrical and electronic components and is not allowed to be disposed of as household refuse. All locally valid regulations and requirements must be observed.




Simple direct mounting Adjustable angle of rotation High functional reliability Cccessories Electrical accessories ectrical installation	Straightforward direct mounting on the ball valve wintegrated in the plug-on position indicator. The measurements be selected in 90°, steps. Adjustable angle of rotation with mechanical end set The actuator is overload-proof, requires no limit set end stop is reached. Description Auxiliary switch SA Feedback potentiometer PA	ounting position in relation to the ball valve ca stops.
High functional reliability ccessories Electrical accessories	The actuator is overload-proof, requires no limit su end stop is reached. Description Auxiliary switch SA	witches and automatically stops when the
ccessories Electrical accessories	end stop is reached.  Description Auxiliary switch SA	
Electrical accessories	Auxiliary switch SA	Data aboat
	Auxiliary switch SA	Data abaat
		Data Sheet
ectrical installation		T2 - SA T2 - PA
Wiring diagram	Open-close control	3-point control
tes aution power supply voltage! arallel connection of other actuators possible. ote performance data. irection of rotation switch is covered. actory setting: Direction of rotation Y2 Direction of rotation Y2	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	
imensions [mm]		
Dimensional diagrams		25 
	R65.	-


· Complete overview of actuators for water solutions


- Data sheets for ball valves
- · Installation instructions for actuators and/or ball valves
- Notes for project planning (hydraulic characteristic curves and circuits, installation regulations, commissioning, maintenance etc.)




## TR..A.. / LR..A.. / SR..A..









## TR..A.. / LR..A.. / SR..A..



